

Roll-A-Ramps

The aluminum roll-a-ramps are easy to deploy and are a great, lightweight solution. To use when stored rolled up, place the rolled ramp on its side and unwind, paying attention to pinch points. A second person will be needed to lift the ramp and place it on the trailer and ground. When setting the ramps, place the wide yellow plate on the back of the trailer door jamb and lower the other end to the ground. Clubhouse recommends placing the ramps side by side with a small gap in between

During loading and unloading, the mid-support stands need to be in place to give the ramp rigidity and safety. To place the stands, slide a stand along the ground until it comes in contact with the bottom of the ramp treads. Then move the stand to the next lowest full tread and sit the tread on top of the triangle at the top of the stand. No tools or pins are needed. Each ramp uses two stands and, with those in place, can support up to one thousand pounds.

To stow the ramps, remove the support stands, then load them flat into a belly box or roll them up and secure them with the provided straps.

Maintenance

- Ensure that the Roll-A-Ramps are stored properly after each use.
- Periodically inspect for any loose or missing fasteners and tighten or replace.