

Belly Box Latches

Belly box doors are held in place with two or three spring loaded latches. To open the belly boxes, push the tab in the center of the latch down, while supporting the latch arm. Once opening the latches on the door, raise the door part-way, then close the arm of the latch back into the flat position of each latch. This will protect the vinyl wrap or paint on your trailer from damage by the latch arm. Raise the door all the way, then slide the hold-back arm into the keeper. The Clubhouse does not recommend using feet to kick open the latches, as you can inadvertently break the latch, or shear the screws or rivets holding the latch on the door.

To close the belly boxes, first release the arm from the holdback keeper, then open all the latches. Lower the door and secure the latches back. The lock symbols indicate the optimal placement of a lock on each belly box.

Please Note: Belly boxes are not water-tight, so Clubhouse recommends their use only for items that do not require water-proof storage.